

Introducing The New Deluxe Water Purifier from EcoWater - EcoWater 800

Here's how easy it is to enjoy to the taste and benefits of pure, crystal clear water, anytime...

Simply fill the main chamber with water from your tap. The water is then heated to 212°F, killing bacteria, eliminating Cryptosporidium, reducing lead, nitrates and other total dissolved solids. This highly effective process removes up to 99% of most substances from the water. The heated water is then converted to steam, which rises, leaving residual chemicals and other impurities behind. Lastly, the water is cooled and dispensed into the collection/serving carafe.

Pure steam is cooled in stainless steel condensing coils

Purifying chamber heats water to 212°F, killing microbiological contaminants and cysts

Removable boiling chamber is filled with nearly 4 Litres of water

LCD Monitor tells the time of day, provides automatic start and/or delay feature, time to change filter indicator and auto shut-off

"Stop & Serve" anti-drip valve lets you neatly and conveniently dispense pure water anytime

Purified water passes through a special carbon polishing filter eliminating any residual taste or odours

Purified water collects in serving carafe ready for immediate use



Introducing The New Deluxe Water Purifier from EcoWater

Convenient

Multi-function clock/timer/monitor lets you know the status of the water you're purifying, provides automatic start-up while you're away (at work or play), tells you when to change the filter and displays the time of day.

It's Easy - No Plumbing Required!

- ❖ Simply plug it in and you're ready to begin enjoying pure, delicious-tasting water anytime!
- ❖ No Tools, no fittings, no soldering, no installation - no problems.

Contaminants Reduced

Arsenic	Bacteria
Barium	Cadmium
Chromium	Copper
Cysts	Fluoride
Lead	Mercury
Nitrate	Selenium
Viruses	

Provides great tasting, pure water your family can trust

- ❖ Produces nearly 23 Litres of Pure Water Per Day
- ❖ Reduces Lead, Arsenic, Nitrates and Sodium
- ❖ Eliminates Cysts (Cryptosporidium and Giardia), Bacteria and Viruses
- ❖ Reduces 99% of Total Dissolved Solids
- ❖ Electronic Clock/Timer/Monitor
- ❖ Attractive Serving Carafe
- ❖ 800 Watts of Power

Other Substances Reduced

Aluminium	Bromide
Calcium	Chloride
Chlorine	Iron
Magnesium	MTBE
Silver	Sodium
Sulfate	Sulfides
Zinc	Taste & Odours

